# SHALLOW DRAUGHT SHIPS FOR THE DANUBE

Dr. Dejan Radojcic, Professor
University of Belgrade, Faculty of Mechanical Engineering,
Dept. of Naval Architecture

Sustainable Navigation Workshop Ruse, Bulgaria October 1st and 2<sup>nd</sup>, 2009

#### Front page of a 110-page Report

# ENVIRONMENTALLY FRIENDLY INLAND WATERWAY SHIP DESIGN FOR THE DANUBE RIVER

WORLD WIDE FUND FOR NATURE INTERNATIONAL DANUBE-CARPATHIAN PROGRAMME (WWF-DCP)

PROJECT NAME: DANUBE NAVIGATION

PROJECT NUMBER: 9E0726.04
CONTRACT NUMBER: 066/FY09


PROJECT EXECUTED BY: **DEJAN RADOJCIC**PROJECT LOCATION: **REPUBLIC OF SERBIA**DATE OF AGREEMENT: **01 JANUARY 2009**SHORT DESCRIPTION OF ASSIGNMENT:

DEVELOPING CONCEPT FOR SHIP DESIGN FOR THE DANUBE RIVER CONDITIONS

# Presentation's structure

- INTRODUCTION (4 slides)
- WATERBORNE TRANSPORT (1 slide)
- TECHNICAL MEASURES THAT MAKE INLAND SHIPS CLEANER AND MORE EFFICIENT (4 slides)
- PROPOSED SOLUTIONS FOR THE DANUBE (8 slides)
- CONCLUSIONS (2 slides)

# **Contemporary trends - Intermodal transport**



- The waterborne transport is only part of intermodal transport chain
- Transhipment costs are often substantial and are accounted to waterborne costs
- The land transport modes "dictate" prices. EU market share Rd/Rl/**IWT**/Pp = 75/13/**7**/5; varies from one country to another
- IWT should adapt itself to other modes and hence standards that are broadly used in Europe (to pallet-wise containers - EILUs)

# General requirements

Operational costs are dramatically reduced with increase of water depth, i.e. increase of vessel draught

- During the low water levels, the ship should be able to operate with restricted economical effects
- The same ship should be able to operate in deeper water too, but will then be less efficient than the ship initially designed for deep-water operation only

# Conclusions

- Transport costs, however calculated, are very much influenced by water depth
- Inland vessels should be designed (matched, adapted) according to the particular waterway

### THE DANUBE WATERWAY

#### Water depth

<u>Upper Danube</u> – stretch Straubing-Vilshofen with h<sub>W-LNRL</sub>< 2 m (1.7 m)

several sectors have  $h_{W-1 \text{ NBI}} = 2.0 - 2.3 \text{ m}$ 

<u>Lower Danube</u> – several sectors have h<sub>W-LNRL</sub>= 2.3 – 2.4 m (1.5 m)

Elsewhere – h<sub>W-LNRL</sub>> 2.5 m. Middle Danube - often above 5 m

#### Bridge height or air clearance

<u>Critical bridges</u> – Deggendorf  $h_{A-HWL}$  = 4.73 m and Passau  $h_{A-HWL}$  = 6.36 m

RMD canal bridges - ~ 6 m

Other bridges - upstream from Budapest ~6.7 m, downstream h<sub>A-HWL</sub>> 7.5 m

#### Size of locks

<u>Critical</u> – Straubing at 12x190 m (as all locks of RDM canal)

Other on the Upper Danube are 2x24x190 m

The rest are 2x34x275 (310) m

#### IMPLICATIONS ON SHIP DESIGN

All-around clearance between the vessel (or her cargo) and bridge/river-bottom/lock-side should be at least **0.3 m**!

#### Maximal allowed vessel dimensions are:

For the whole Danube and DM Canal: T < 1.7 m (probably 2 m),  $B \le 11.45$  m Downstream of Vilshofen: T < 2.0 m (probably 2.5 m),  $B \le 23.4$  m The length of self-propelled vessels is practically unrestricted Length of coupling train formation should be checked

#### In the shallow water, three characteristic regimes exist:

 $\frac{\text{Sub-critical}}{\text{Critical}} \text{ (according to ITTC, bellow } F_{nh} = 0.7)$   $\frac{\text{Critical}}{\text{Critical}}, \text{ where } P_{B} \text{ increases dramatically}$   $\frac{\text{Super-critical}}{\text{Super-critical}}, \text{ where } P_{B} \text{ may be smaller than in deep water}$ 

High speed vessels generate large wake (wash) which may cause serious bank erosion. So, the critical and near-critical speeds should be avoided due to environmental reasons as well.

#### WATERBORNE TRANSPORT

#### PREVIOUS RESEARCH

Barge trains (for transport of large quantities of relatively cheap cargo)

- •<u>Partly loaded barges</u> can be the simplest and cheapest answer to restricted draught problems (taking into account that power needed to push an additional barge (or few of them) rises slightly, while cargo volume can increase rapidly
- The problem usually poses the draught of a pushboat which cannot be reduced. So, a shallow draught pushboat would be advantageous in these situations

Selfpropelled vessels (for general, bulk and liquid cargo)

<u>Selfpropelled vessels are faster</u> and therefore more suitable for container transport (which has to compete with land transport modes, i.e. railway and truck)

<u>Statistics:</u> Rhine 84% & 34% and Danube 4% & 44% of European selfpropelled and pushed barges fleet, respectively

\_\_\_\_\_

<u>Previous projects of particular interest</u> - *INBISHIP, VEBIS* and *INBAT*The main reason why the innovative ship types are not applied in broader scale is <u>economics</u> (the state subsidies should be considered)


#### TECHNICAL MEASURES THAT MAKE INLAND SHIPS CLEANER AND MORE EFFICIENT


"It's not easy being green" . The main technical measures **Kermit the Frog** that enable fuel efficiency, hence cleaner and therefore more environmentally friendly **Fuel Efficient Ship for IW** shipping, are divided into four main groups Improvements in Improvement of Ship **Propulsion and Improvement** in **Improvement** in Utilisation **Propulsion Plant Transmission Hull Resistance** (Navigation) **Efficiency** Necessary crew and shore-personnel training Shallow water effects Efficient propulsors New generations of (choice of main (propellers, water jets etc) Diesel engines parameters) River Information Services (RIS) New power transmissions Hull lines (mechanic, hydraulic, Other engine types (Bow & Stern form) electric) Speed adjusting to specific waterway situation Reduces fuel Increases  $\eta_D \eta_S$ Weight consumption reduction Reduces v Fuel Consumption =  $f(P_R) = R_T \cdot v / \eta_D \cdot \eta_S$ Reduces R<sub>T</sub>

#### TECHNICAL MEASURES THAT MAKE INLANDSHIPS CLEANER AND MORE EFFICIENT

# **Conclusions**

•Involve the <u>hydrodynamic</u> expertise an early design stage






- Reduce <u>hull weight</u> where possible (during ship production)
- New propulsor types should be considered
- New <u>engine types</u> should be considered for ship applications
- Command-bridge computerisation
   (RIS and other achievements)
- Crew training





#### TECHNICAL MEASURES THAT MAKE INLANDSHIPS CLEANER AND MORE EFFICIENT

# **AN INTERESTING TOPPIC - EMISSION LEGISLATIONS**




Ship Diesel engines have  $\mathbf{CO_2}$  emissions lower than the truck engines, while  $\mathbf{NO_X}$ ,  $\mathbf{PM}$  and  $\mathbf{SO_X}$  emissions are higher

CCNR norms are assumed to be relevant for IWT

- <u>Time lag</u> in implementation of EURO & CCNR emission regulations
- Ship have a lifetime of at least 20 years vs. 5 years for trucks
- Precondition for low emissions is a <u>low sulphur fuel</u>

#### TECHNICAL MEASURES THAT MAKE INLANDSHIPS CLEANER AND MORE EFFICIENT

# Comparison of emissions emitted by considered IWW ships and a truck on the basis of tkm



Ships are NOT so clean in terms of NOx and PM, unless Emission Reduction Technologies (ERT) are applied

Standards according to CCNR III (corresponding to EURO V) may be met only by application of ERT

Emission Reduction Technologies - ERT consist of several compatible and complementary measures:


- First step Reduction of allowed sulphur for marine oil diesel
- <u>Second step</u> Application of new diesel engine technologies and exhaust gas cleaning (older engines should be retrofitted with after-treatment devices)

With the aim to demonstrate how a contemporary, safe, cost-effective, shallow draught vessel intended particularly for the Danube waterway should look like, some of the conclusions and technical achievements aimed at increasing efficiency of inland navigation are incorporated into design of two specific ship types:


- Selfpropelled container vessel
- Barge train (actually a pushboat) for bulk cargo

These two distinct ship type concepts are chosen because they are good representatives of typical ships used on the Danube

# Danube container ship concept - Diesel-electric propulsion



Enlarged engine room



# Main particulars of container ship concepts

HAHAMAN		Config	Configuration		
		Basic	With a Crane		
Length	m	104.0	102.5		
Beam	m	11.65	11.65		
Height (Depth)	m	3.1	3.1		
Draught (max)	m	2.5	2.5		
Hold length	m	80.0	78.5		
Hold width	m	10.34	10.34		
Height above basis line	m	8.3	8.3		
Installed power	kW	4 x 400	2 x 700		
TEU (3 layers / 4 layers)		156/208	134/172		
Payload capacity	t	1950	1800		

# Some of the concept's features

Special attention was paid to <u>low-draught performance</u>. Proposed concept should be able to operate successfully and therefore be cost-effective at both <u>low draught of up to 1.7–1.8 m</u> (with two container layers) and full draught of up to 2.5 m (with 3 layers of full containers or even 4 layers of mixed full and empty containers)

The chosen hold length (80 m) and breadth (10.25 m) allow stowing of a variety of 2.50-2.55 m wide domestic containers

An on-board crane would allow transhipment at any port

Rudder propulsors enable exceptional manoeuvring characteristics

Position of the engine room at the stern and the crew premises at the bow offers additional crew comfort

# Barge train for transport of bulk cargo


- The main advantage of barge transport is that <u>cost-effective sailing with</u> reduced draught, with partly loaded barges, may be utilized
- To substitute reduced carrying capacity, the <u>number of barges in a convoy</u> <u>might be increased</u> (power needed for pushing this convoy would not increase proportionally).

Tonnage capacity at reduced draught of a typical Danube barge (77x11x2.8 m) are given below:

Draught [m]	~0.5	1.0	1.5	2.0	2.5
Tonnage [t]	-	300-400	700-800	1100-1200	1500-1600

A <u>low draught pushboat</u> with a power of around 2000kW would be advantageous on the Danube

# General Arrangement plan of a pusboat concept



#### Main particulars of pushboat concept

Length	m	30.0
Beam	m	11.0
Height	m	2.5
Draught	m	1.4
Height above basis line	m	6.0
Installed power	kW	3 x 700
Bow thruster	kW	250-300
Crew		8

# The main advantages of the proposed pushboat concept

Its extremely <u>low draught of only 1.4 m</u> (compared to draught of above 1.7 m of similar conventional pushboats)
This enables navigation with partly loaded barges on the whole Danube even at LNRL

Chosen length of 30 m and breadth of 11 m enables good packing possibilities of various push train formations

Enhanced manoeuvring (thanks to gondola-type bow thruster of 250 to 300 kW)

Application of the latest technological achievements that increase efficiency, safety, cleanliness and comfort

These benefits, however, are not a result of the proposed pushboat concept, but rather of a modern era. Namely, almost all Danube pushboats were built 30 or so years ago and therefore were equipped according to the standards belonging to the previous technological generation, so a newly built pushboat of any design or concept will be advantageous compared to the old (conventional) ones


# CONCLUSIONS

- Contemporary (modern) shallow draught vessels, particularly suited for the Danube waterway are <u>feasible</u> (and desirable)
- They are <u>inherently less efficient and less cost-effective</u> (if water is deep enough) than the vessels with deeper draught
- •When there is not enough water (when LNRL) low draught vessels will have a <u>logistical advantage</u> compared to deeper draught vessels as will be able to navigate all the year round
- •Under which conditions IWT will work (i.e. what would be minimal/guaranteed water depth along the river and throughout the season, cost of fuel, taxes, eventual state subsidies etc.) is a <u>political question</u> which should be influenced, amongst other, by the technical and ecological requirements of IWT

### COMMENT

Ships were navigating in the past although navigational conditions were worse (with a lot of shallows and free-flowing sectors), but the business environment was then different than it is today (with pipelines, railway and road infrastructure passing through the Danube corridor).

Under the present circumstances, there may be a limit (concerning low draught navigation) under which IWT will not be cost-effective anymore, as other modes, already much stronger and better positioned, will prevail.



Towing with the assistance of rail locomotives in Sipski kanal, Danube km 944+2200 m, right bank (current speed up to 18 km/h), from 1918 till the beginning of 1970